
### Fisher-Price® Smart Connect™ App

- Some features of this product only work with the Fisher-Price® Smart Connect™ app.
- Download the Fisher-Price<sup>®</sup> Smart Connect<sup>™</sup> app to control the sleeper from your smart device (not included). The app is available on the App Store<sup>®</sup> and Google Play<sup>™</sup>.
- The Smart Connect™ app is compatible with most iOS and Android™ devices. Please refer to the chart for a list of compatible devices. Device not included.

### **Pairing Your Device with Soother**


Before using the Fisher-Price® Smart Connect™ App for the first time, pair your device (not included) with the soother.



- Open the Fisher-Price® Smart Connect™ App on your device. Be sure your device is within approximately 1,8 meters of the soother to pair.
- Press and hold the pairing button (the power button) 0 on the soother for 5 seconds to pair it with your device. Once paired, you'll see a green button light on your device.


Hint: If you cannot pair your device with the soother, try moving the device closer to the product.

### The soother of your dreams ....




- Touch the **power button** to turn ON. Touch again to turn power OFF. When you turn power back on, the soother recognizes the most recent music/sounds/light selections.
- Touch the **sleep sounds button** to turn on soothing sounds. Touch again to change the sound. Each touch advances to a different sound: Pink Noise, Brown Noise, Womb Sounds, Ocean Waves, Nature or Wind. Press and hold this button to turn off sounds.
- Touch the **music button** to turn on gentle music. Touch again to change to a different music selection. Each touch advances to a different music selection. Press and hold this button to turn off music.
- Touch the **volume button** to increase volume. Touch again and again to increase volume level and then turn volume off. Your next touch sets volume at it's lowest level again. Press and hold this button to turn volume off.
- Touch the **animal projection button** to turn on enchanting projection. Touch again to turn projection off.
  - Touch the **star projection button** to turn on multi-colored projection. Touch again to turn projection off.
- Touch the **nightlight button** to turn on a soft, amber nightlight. Touch again to turn the nightlight off.

#### Fisher-Price® Smart Connect™ App




# Animal Projection






Reset all Settings


# Star Projection







## Music



# Sleep Sounds


Touch a button for Pink Noise, Brown Noise, Womb Sounds, Ocean – Waves, Nature or Wind sounds.



12

Reset all Settings

#### **Timers**






Hint: When in Sleep Stages mode, you cannot modify music, sounds or lights.



**Hint:** In this mode, the buttons on the soother will blink in sequence.



Keep the slider on Settle for three Sleep Stages (Settle, Soothe and Sleep); move it to Soothe for two Sleep Stages (Soothe and Sleep) or move it Sleep.