


Fisher-Price® Smart Connect™ App

- Some features of this product only work with the Fisher-Price® Smart Connect™ app.
- Download the Fisher-Price® Smart Connect™ app to control the sleeper from your smart device (not included). The app is available on the App Store® and Google Play™.
- The Smart Connect™ app is compatible with most iOS and Android™ devices. Please refer to the chart for a list of compatible devices. Device not included.


Pairing Your Device with Soother

Before using the Fisher-Price® Smart Connect™ App for the first time, pair your device (not included) with the soother.










- Open the Fisher-Price® Smart Connect™ App on your device. Be sure your device is within approximately 1,8 meters of the soother to pair.
 - Press and hold the pairing button (the power button)  on the soother for 5 seconds to pair it with your device. Once paired, you'll see a green button light on your device.
- Hint:** *If you cannot pair your device with the soother, try moving the device closer to the product.*

The soother of your dreams



More features are available using the **Fisher-Price® Smart Connect™ App**

- Program Sleep Stages for baby's bedtime routine;
- Choose light colors, brightness and sequences;
- Make music style selections;
- Use your device to control volume;
- Use your device to turn soother power ON or OFF.

-  Touch the **power button** to turn ON. Touch again to turn power OFF. When you turn power back on, the soother recognizes the most recent music/sounds/light selections.
-  Touch the **sleep sounds button** to turn on soothing sounds. Touch again to change the sound. Each touch advances to a different sound: Pink Noise, Brown Noise, Womb Sounds, Ocean Waves, Nature or Wind. Press and hold this button to turn off sounds.
-  Touch the **music button** to turn on gentle music. Touch again to change to a different music selection. Each touch advances to a different music selection. Press and hold this button to turn off music.
-  Touch the **volume button** to increase volume. Touch again and again to increase volume level and then turn volume off. Your next touch sets volume at it's lowest level again. Press and hold this button to turn volume off.
-  Touch the **animal projection button** to turn on enchanting projection. Touch again to turn projection off.
-  Touch the **star projection button** to turn on multi-colored projection. Touch again to turn projection off.
-  Touch the **nightlight button** to turn on a soft, amber nightlight. Touch again to turn the nightlight off.

Fisher-Price® Smart Connect™ App

View your device status here. Touch to disconnect. Touch again to connect.

Touch to start your selections. Touch again to turn off.

Touch to make Sleep Stages selections and turn on.

Touch a tab to make customized selections for Animal Projection, Star Projection, Night Light, Music, Sound Effects and Timers.

Reset all Settings


Touch to reset customized settings.




Animal Projection



Touch to turn on animal projection.




Slide to increase or decrease projection brightness.





Star Projection



< Home

Soother 2 >

Deluxe Soother

You're connected!



Animal Projection

Star Projection



Touch to turn on star projection.

Star Brightness



Slide to increase or decrease projection brightness.

Speed



Slide to choose color change speed.

Color Combination



Touch to choose preset color combinations: all colors, blue and green or yellow and red.

Custom Color



Touch any three colors to create your own custom setting.

Night Light


Music

Sound Effects

Timers

Reset all Settings

Night Light



The screenshot shows the 'Deluxe Soother' app interface. At the top, there are navigation arrows for '< Home' and 'Soother 2 >'. Below this is the title 'Deluxe Soother'. A status indicator shows a grey circle and the text 'You're connected!'. To the right is an image of the Soother device. Below the image are two play buttons. A list of settings follows: 'Animal Projection', 'Star Projection', 'Night Light', 'Music', 'Sound Effects', 'Timers', and 'Reset all Settings'. The 'Night Light' section is expanded, showing a toggle switch and a brightness slider. The toggle switch is currently in the 'off' position. The slider has a minus sign on the left and a plus sign on the right, with a circular knob positioned towards the right side.

Touch to turn on night light.

Slide to increase or decrease projection brightness.

Music

The screenshot shows the Music app interface for a 'Deluxe Soother'. At the top, there are navigation options '< Home' and 'Soother 2 >'. Below this is the device name 'Deluxe Soother' and a status 'You're connected!' with a grey dot. A large play button is on the left, and an image of the soother is on the right. Below are three feature buttons: 'Animal Projection', 'Star Projection', and 'Night Light'. The 'Music' section is highlighted, showing 'Six Lil Ducks' as the current playlist. It features a 'Settle Music' section with a gear icon and a row of five numbered buttons (1-5). Below that is a 'Soothing Music' section with a wave icon and another row of five numbered buttons (1-5). A volume slider is positioned below the Soothing Music buttons. At the bottom are 'Sound Effects', 'Timers', and 'Reset all Settings' buttons.

< Home Soother 2 >

Deluxe Soother

● You're connected!

▶

▶

Animal Projection

Star Projection

Night Light

Music Six Lil Ducks

⚙️

Settle Music

Touch to turn on Settle music.

Touch and hold to remove a song from the playlist.

2 3 4 5

Touch a number to immediately start that song.

Touch a number to immediately start that song. Touch and hold to remove that song from a playlist.

⋈

Soothing Music

1 2 3 4 5

Volume 🔊


Slide to increase or decrease volume.

Sound Effects

Timers

⚙️ Reset all Settings


Sleep Sounds



Touch a button for Pink Noise, Brown Noise, Womb Sounds, Ocean Waves, Nature or Wind sounds.

Slide to increase or decrease volume.

Timers



Touch from 5 minutes to continuously on.

Touch to choose how long you would like animal projection, star projection or night light to be on.


Touch to choose how long you would like music or sounds to be on.



Sleep Stages

Hint: When in Sleep Stages mode, you cannot modify music, sounds or lights.

Hint: In this mode, the buttons on the soother will blink in sequence.



Touch to turn on Sleep Stages. The soother progresses through Sleep Stages selected below.

Keep the slider on Settle for three Sleep Stages (Settle, Soothe and Sleep); move it to Soothe for two Sleep Stages (Soothe and Sleep) or move it Sleep.

Touch to choose how long you would like each selected stage to be on.