



PAIRING YOUR DEVICE

Before using the Smart Connect™ app for the first time, you will need to pair your device with the glider.



Open the Smart Connect™ app on your device. Be sure your device is within approximately 1,8 m (6 ft) of the glider to pair.

Press and hold the pairing button (power button) on the glider control panel for about 5 seconds. The glider stays in pairing mode for approximately 30 seconds.

Hint: If you cannot pair your device with the glider, try moving the device closer to the glider.

The glider icon will be highlighted in green in the app when the glider is connected to your device. This indicates that you can use your device to control the glider.

SMART CONNECT™ APP

App features and decorations shown in photographs and illustrations may vary.

Touch to customize the glider name.

< Menu


3-in-1 Soothe 'N Play Glider



You're connected!

Touch to connect or disconnect your device from the glider.

Touch to start selections (gliding, sounds or music). Touch again to pause.



Touch to decrease gliding speed.

Glider Speed



Touch to increase gliding speed.

Choose the amount of gliding time.



Glider Timer >

Learn More

Soothe Stages




Touch to start settling music that transitions to calming music. Make sure you choose the amount of time for each stage.

Music & Sound Effects



Touch and drag the button to increase or decrease volume.

Volume



Touch a button to choose music or sound effects.

Choose how long you'd like music or sound effects to entertain baby.



Music Timer >

Save Settings



You can save up to two custom settings.