


# Pairing Your Device

Before using the Smart Connect™ app for the first time, you will need to pair your device with the mobile.



Pairing Button

- Open the Smart Connect™ app on your device. Be sure your device is within approximately 6 ft (1,8 meters) of the mobile to pair.
  - Next, slide the mobile power switch ON.
  - Then, press the pairing button on the back of the mobile. The mobile will stay in the pairing mode for approximately 30 seconds.
- Hint:** If you cannot pair your device with the mobile, try moving the device closer to the mobile.
- The mobile icon will be highlighted in green in the app when the mobile is connected to your device. This indicates that you can use your device to control the mobile.

# Smart Connect™ App


Press the mobile icon to open the mobile controls.



Press the switch icon to turn the Smart Messages ON or OFF. When Smart Messages are enabled you will receive pop-up notifications on your device to tell you the status of your mobile.

Press the Music on the Go icon to play mobile songs from your device.

Press the back icon to return to the home screen.



Press the play/pause icon to start or stop music.

Press the forward or reverse icons to change the song.

Press the playlist icon to create a custom playlist from songs on your device.

Press the animation icon to choose a display image for your device.

# Smart Connect™ App

View your device status here:  
**You're Connecting, You're Connected, You're Not Connected or Your mobile is out of range, turned off or asleep.**

Press to connect or disconnect your device from the mobile.

Press to customize mobile name.

Press to choose how long the mobile will stay on.

Press to turn the check light ON. Press the icon again to turn the check light OFF.

Press to turn the mobile ON. Press the icon again to turn the mobile OFF.

Press to turn the mobile and projector ON. Press the icon again to turn the mobile and projector OFF.

Press to choose how long music/sounds will play.

Press to turn the music/sounds ON. Press the icon again to turn music/sounds OFF. Press the music or nature sounds icon a third time to play a different song/sound effect.

Press to adjust volume level.


*Hint: Music/sound effects must be ON to use this feature.*

Press to turn the Sound Sensor Smart Messages ON. Press the icon again to turn OFF.

**Hints:** This feature can only be used when music/sounds and mobile/projector are turned OFF. The sound sensor will display a pop-up message if a sound is detected in baby's room.

Slide to adjust the sensitivity level of the sound sensor.

This icon displays the battery life of your mobile. When the battery icon turns red or is at 0%, it's time to replace the batteries.



# Smart Connect™ App Compatibility

The Fisher-Price® Smart Connect™ app is compatible with the devices listed in the table.

APPLE	ANDROID
<ul style="list-style-type: none"><li>• iPhone (6 Plus, 6, 5S, 5C, 5 &amp; 4S)</li><li>• iPad (mini with Retina display, mini, Air, 4th &amp; 3rd gen) or newer</li><li>• iPod touch (5th gen)</li></ul>	<ul style="list-style-type: none"><li>• Google Nexus 5, Nexus 4</li><li>• Google Nexus 7 (2013), Nexus 10</li><li>• HTC One, One Max</li><li>• Motorola Moto G, X</li><li>• Samsung Galaxy S3 or newer</li><li>• Samsung Galaxy Tab 4, Pro, S or newer, Galaxy Note 3, Galaxy Note 8, 10.1, Pro 12.2, or newer, Galaxy Mega</li><li>• Sony Xperia (SP, Z, ZR, ZL, Z1, Z Ultra HSPA+)</li><li>• Sony Xperia Tablet Z</li></ul>

As technology changes, this app may become compatible with additional devices. Visit [fisher-price.com/SmartConnect](http://fisher-price.com/SmartConnect) for an up to date, complete list of compatible devices.